


SmartWasher® Model SW-18 and SW-28 SuperSink Base Diagram

Model 1 Control Box ; 4-LED Control Box with Clear Lid ; 4-LED 12" Control Box
*SW-18 and 4-LED SW-28 Models No Longer Manufactured
 (some replacement parts may be obsolete)*



HEATER BOX ASSEMBLY 110v 4435-HTBAY (Toggle Switch Control)
 SW-25/SW-15/SW-18/SW-28
 SW-15C/SW-25C
 (includes: heater, probe, box & fittings)

SINK KIT 4425-SKPKT-SS
 SW-08/SW-18/SW-28/SW-48
 (includes: liquid tight tubing, connectors, and plumbing to sink)

PUMP ASSEMBLY 110V 4475-PMASY-110
 SW-05/SW-45/SW-25/SW-15
 SW-18/SW-28/SW-15C/SW-25C
 (includes: pump, liquid tight tubing, quick connects & tubing for plumbing)