

## Replacement Instructions for SW-23 HEATER BOX ASSEMBLY

**Tools Required:** Phillips head screwdriver, 1¼" socket wrench with 3" or larger extension, slip joint pliers, 3/8" nut driver, drill and 3/16" drill bit, pliers, safety gloves, shop towel

**Before beginning**, pump any fluid from the machine into buckets or empty fluid boxes. This will make changing the parts easier and provide a chance to clean out any sludge buildup that may be in the base.

1. Unplug the SmartWasher from the power source.
2. Remove the quick release pins that secure the sink to the base.
3. Disconnect the sink hose from the base by releasing the metal rings on the quick connect coupling.
4. Remove the sink and set aside.
5. On the outside of the base, detach the control box lid by removing four screws with the Phillips head screwdriver.
6. On the inside of the base, detach the heater box lid by removing four screws with the Phillips head screwdriver. **BE CAREFUL NOT TO DROP THE SCREWS INTO THE BASE.**
7. Disconnect the probe cable from the control board. Using the pliers, disconnect the pump wires (left) and heater wires (middle) from the control board. \*\*\*See diagram\*\*\*
8. Feed the pump wires from the control box through the bulkhead fitting into the heater box inside of the base. Repeat this with the heater wires and the probe cable. Tie the heater wires and probe cable into a loose knot to keep them from falling into the base.
9. Use the slip joint pliers to loosen the grey liquid tight connector for the pump on the side of the heater box. Disconnect the grey liquid tight tubing from the liquid tight connector.
10. Pull the pump wires from the heater box through the liquid tight connector. Loosely tie the pump wires to the other pump hose so that they do not fall into the base.
11. Use the 3/8" nut driver to hold the nut inside of the heater box. Using the Phillips head screwdriver, loosen and remove the screw inside of control box. Set the nut and screw aside to be reused on the new heater box.
12. Use the 1¼" socket and slip joint pliers to remove the bulkhead fitting nut inside of the heater box. Remove the washer and nut from inside of the heater box. Carefully remove the heater box, including the probe and heater, from the base. Remove the rubber washer located on the bulkhead fitting between the heater box and the inside wall of the base and set aside.
13. Using the slip joint pliers, remove the liquid tight connector from heater box. Discard old heater box assembly.
14. Install the liquid tight connector into the new heater box assembly using the slip joint pliers.
15. Tie the heater wires and probe cable in a loose knot.
16. In the base, replace the rubber washer that was removed with the heater box assembly (between the wall of the machine and the heater box). Place the new heater box assembly on the bulkhead fitting. Replace the washer inside the heater box and tighten the bulkhead fitting nut. To fully tighten, use the 1¼" socket and slip joint pliers.
17. Using the 3/16" bit, drill through the existing hole in the control box and base into the new heater box. Insert the screw into hole and tighten using the 3/8" nut driver. This screw provides extra support to the bulkhead fitting.
18. Untie the pump wires from the pump tubing and pull through the grey liquid tight connector into the heater box. Firmly push the grey tubing into liquid tight connector. Hand tighten the liquid tight compression nut. Use the slip joint pliers to tighten an additional ¼ turn.
19. Untie the loose knot of probe and heater wires. Feed the probe cable through the bulkhead fitting into the control box and connect to the control board. \*\*\*See diagram\*\*\*
20. Feed the pump wires through the bulkhead fitting into the control box and connect to the control board. From top to bottom, the wires should be: brown, blue, and yellow/green. \*\*\*See diagram\*\*\*
21. Feed the heater wires through the bulkhead fitting into the control box and attach to the control board. From top to bottom, the wires should be: black, black, and yellow/green. \*\*\*See diagram\*\*\*
22. Replace the heater box lid and tighten the screws using the Phillips head screwdriver. **BE CAREFUL NOT TO DROP THE SCREWS INTO THE BASE.**
23. Replace the control box lid and tighten the screws using the Phillips head screwdriver.
24. Replace the sink. Plug the quick release pins back into the sides of the base. Reconnect the sink hose and push the metal rings toward the base to lock into place.
25. Replace the fluid in the base of the SmartWasher. Plug unit into power source and test.

If you have any questions about these procedures or if your SmartWasher is configured differently than described in these instructions, PLEASE CALL CHEMFREE CUSTOMER SERVICE AT 1-800-521-7182 or visit us on the web at [www.chemfree.com](http://www.chemfree.com) for more detailed instructions, including instructional videos.

# Control Box Assembly



PROBE CABLE

PUMP WIRES

- Brown
- Blue
- Yellow/ Green

- Black
- Black
- Yellow/ Green

HEATER WIRES

BULKHEAD FITTING

# Base Assembly (interior)



Heater Box

Heater Box Lid

Probe

Heater

Liquid Tight Connector

Liquid Tight Tubing