


SmartWasher® Model SW-15 & SW-25 Signature Series Base Diagram

Model 1 Control Box ; 4-LED Control Box with Clear Lid ; 4-LED 12" Control Box

*SW-15 and 4-LED SW-25 Models No Longer Manufactured
(some replacement parts may be obsolete)*



**HEATER BOX ASSEMBLY 110v
4435-HTBAY
(Toggle Switch Control)
SW-25/SW-15/SW-18/SW-28
SW-15C/SW-25C
(includes: heater, probe, box
& fittings)**

**SINK KIT
4425-SKPKT
SW-15/SW-15C/SW-25/SW-25C
SW-05/SW-45
(includes: liquid tight tubing,
connectors, and plumbing to sink)**

**PUMP ASSEMBLY 110V
4475-PMASY-110
SW-05/SW-45/SW-25/SW-15
SW-18/SW-28/SW-15C/SW-25C
(includes: pump, liquid
tight tubing, quick connects
& tubing for plumbing)**