

SMARTWASHER REPLACEMENT PARTS LIST: Effective May 1, 2014 (FREIGHT: FOB; NORCROSS, GA 30093)

SW37		SW37			
SW37		Part #	Description	Notes	Machine
SINK	1032-FABOT-37		False Bottom for SW-37		37
	1400-DBSKT		Drain Basket mesh 3½" ss		37
	1410-MSGRD-PL		Mat Support Grid		37
	1475-HOLEC-37		Hole Cover for 37 Sink		37
	1490-QCINS-12		Quick Con ½ insert coup, M x hose barb		37
	1530-BASKT		Basket plastic for 23 / 37		37
	1555-VELST		Velcro strap 18"	for power cord	37
	1600-BUSHG		Valve Bushing		37
	1605-ADAPT-12		½" NPT Connector Gray		37
	1605-CLAMP		Clamp ½" LocLine Gray		37
	1607-GMVAL-12		Valve male barb x ½" Male NPT		37
	1608-BVALV-12		½" Ball Valve PVC GRAY		37
	1630-FELBO-12		Elbow ½" F x ½" F PVC40 BLACK		37
	4415-NVKIT-STD		½" Ball Valve Kit for Nozzle 25/28/25C/37		37
	4425-SKPMP-37		Sink to Pump Kit for SW-37		37
	4538-ABRSY-4		Angled Brush Assembly w/ 4-ft hose		37
4550-NOZKT-SS		Super Sink Nozzle Kit		37	
BASE	1270-PROBE-37		Probe plastic grey for 37		37
	1278-FUSEH-110		Fuse 5-LED cont bx 110v HTR		37
	1278-FUSEP		Fuse 1A, 250V for PUMP		37
	1280-TOGSW		Toggle Switch for Control Box		37
	1281-BOOTS		Boot for toggle switch		37
	1485-CASTB-5		Caster 5" for SW-37 with brake		37
	1485-CASTR-5		Caster 5" for SW-37 (no brake)		37
	1486-WHEEL-10		Wheel 10" for SW-37		37
	1520-COTPN		Cotter Pin Auto-Lock ss ¼"		37
	4015-DLYKT-37		Dolly Kit for SW-37		37
	4020-OVRFL-37		Overflow Assemblby for 37 base		37
	4050-HTASY-110		Heater Assembly for 37 110v		37
	4100-CONTR-37		Control Assembly for 37 110v		37
	4138-CBASY-37		Control Box Assembly 110v 5-LED for 37		37
	4160-CDSKT-110		Power Cord - 110v, 12 ft KIT	includes power cord & quickconnects	37
	4467-PMPHK-37		Pump Hose Kit for SW-37		37
4470-PMASY-37		Pump Assembly 110v for SW-37		37	